




[Reading the display]




[Readjusting errors up to ±30 seconds]



[Setting the time display (Example: 10:58 PM)]



[Setting the calendar display (Example: June 12 Monday)]



[Time difference adjustment (reversion to normal time display)]

In case of time difference adjustment, press the **B** button instead of the **A** button and the watch reverts to the normal time display.

(Independent correction)

Correction of any digit, if not required, can be skipped by pressing the **A** button repeatedly.

Note: As the calendar system is set at 28 days for February, reset March 1 to February 29 in each leap year.