



[Reading the display]




[Readjusting errors up to ±30 seconds]

Precise time can be maintained by correcting the seconds once a month on a time signal from a radio, TV, telephone, etc.



[Setting minutes and hours]



[Eye-catching display for showroom demonstration]

Press (B) for three seconds or more, and the facia starts to pulsate with two alternate displays — accumulated seconds and the seconds hand, until a button is pressed.

