



# Module No. 350/401/501/592/681/692/695/895

## READING THE DISPLAY



[Module No. 895]

\*The battery of Module No. 895 is not replaceable. Battery life, therefore, is the life of the model.



## READJUSTING ERRORS UP TO ±30 SECONDS

1. Press **B**. Second digits start flashing.
2. Press **A** on a time signal.

Precise time can be maintained by correcting the seconds once a month on a time signal from a radio, TV, telephone, etc.

## SETTING TIME AND CALENDAR


1. Press **B** twice to set hour digits. One hour advances with every push of **B**. Check whether the PM indicator is lit.
2. Press **B** to set minute digits. One minute advances with every push of **B**.
3. Press **B** to set month digits. One month advances with every push of **B**.
4. Press **B** to set date digits. One date advances with every push of **B**.
5. Press **B** to complete.

(Auto-retrieve function) When setting the watch, if you leave it alone for 1 to 2 minutes, the display will automatically return to the regular timekeeping mode.

Note: As the calendar system is set at 28 days for February, reset March 1 to February 29 each leap year.

# Module No. 400/580/586

## READING THE DISPLAY



(Changeover between 12-hour and 24-hour formats) In regular timekeeping mode, with every push of **A**, the display is switched between 12-hour and 24-hour formats.

## READJUSTING ERRORS UP TO ±30 SECONDS

1. Press **B**. Second digits start flashing.
2. Press **A** on a time signal.

## SETTING TIME AND CALENDAR

1. Press **B** twice to set hour digits. One hour advances with every push of **A**. Check whether the PM indicator is lit.
2. Press **B** to set minute digits. One minute advances with every push of **A**.
3. Press **B** to set month digits. One month advances with every push of **A**.
4. Press **B** to set date digits. One date advances with every push of **A**.
5. Press **B** to set day digit. One day moves to the next with every push of **A**.
6. Press **B** to complete.

Note: As the calendar system is set at 28 days for February, reset March 1 to February 29 each leap year.