



[Reading the display]




[Reading the calendar display]



The stationary dash indicates all the Sunday's in the month. The display advances by a month with every push of the B button. The display reverses by a month with every push of the L button. The dash flashing simultaneously with the day letters moves forward a day with every push of the C button. When the A button is pressed, the display reverts to the time display. At the same time, the calendar display automatically returns to the current month.


[Presetting alarm time]



Every time the B button is pressed in the alarm setting mode, the alarm-ON-mark appears or disappears. When the alarm-ON-mark is lit, the buzzer sounds for 30 seconds at the preset time every day until cleared. To stop the buzzer while sounding, press the L button in the time display.

[Sound demonstration] While the A and C buttons are pressed simultaneously, the buzzer sounds.

[Setting time and calendar]



* Divide the year number by 4 and set the remainder if any:

(Ex.) $1978 \div 4 = 494 \dots \text{rem: } 2$

Remainder to be set	The year			
0	---	1980	1984	1988
1	---	1981	1985	1989
2	1978	1982	1986	1990
3	1979	1983	1987	1991

(Independent correction)

Correction of any digit, if not required, can be skipped by pressing the C button repeatedly.

(Reversion to normal time display)

The watch reverts to the normal time display if the B button is pressed, regardless of the digit setting mode.

(Automatic digit advance)

When the A button is kept pressed for more than 2 seconds, the digit advances automatically. When released, the digit advance will stop.