



## [Reading the display]




## [Setting daily alarm]

If the daily alarm is set, the buzzer sounds for 20 seconds at the preset time every day until cleared. To stop the buzzer, press the **C** or **D** button.  
If the time signal is set, the watch sounds every hour on the hour.  
**(Sound demonstration)** Press and hold the **C** button in alarm mode to sound the buzzer.




## [ON or OFF setting of daily alarm and time signal]



## [Stopwatch operation]

A signal confirms start/stop operation.  
**[Working range]** The stopwatch display is limited to 59 minutes 59.99 seconds, for longer times reset and started again.




## [Golfer's stroke count]


This memorizes player's strokes over a half-round.

Press **C** everytime the player hits a ball.  
Press **A** everytime the player holes out.

**[Working range]**  
Total stroke count is limited to 99. Thereafter it is reset and started again.  
Hole counter is limited to 9. Thereafter it is reset and started again.



## [Golf game operation]




- Press **A** to move the mode to golf game mode.
- To select a club from Sand wedge (SW), Pitching wedge (PW), 9, 7, 5, 3 irons and driver (W1), press **C**.
- Press **C** to hit a ball. No need to select a direction when the ball is teed.
- Press **C** to select the right direction from a maximum 8 directions.
- On the green, press **C** to select direction and press **C** to select putting strength and press **C** to putt a ball.
- Repeating steps 2 to 5 will progress you from the first hole to No. 9 hole.
- Press **A** to replay.

**[Bunker]**  
A flashing bunker indicates ball is in the bunker. Hit out when bunker rim disappears.

**[O.B. (out of bounds)]**  
If the ball is out of the display it is O.B.

## [Setting time and calendar]



- [Quick digit advance]** When the **C** button is pressed for more than 2 seconds, the digit advances quickly. When released, the digit advance will stop.
- [Independent correction]** Correction of any digit, if not required, can be skipped by pressing the **A** button repeatedly.
- [Reversion to normal timekeeping mode]** The watch reverts to the normal timekeeping mode if the **A** button is pressed, regardless of the digit setting mode.
- [Auto-retrieve function]** Any setting display will automatically return to the regular timekeeping mode in 2 or 4 minutes.