


OPERATION CHART: MODULE QW-1104

READING THE DISPLAY



Changeover between 12-hour and 24-hour formats
In regular timekeeping mode, with every push of ⓐ, the display is switched between 12-hour and 24-hour formats.

SETTING DAILY ALARM

If the daily alarm is set, the buzzer sounds for 20 seconds at the preset time every day until cleared. To stop the buzzer, press the ⓐ button. If the time signal is set, the watch sounds every hour on the hour.


Sound demonstration

Press and hold the ⓐ button in alarm mode to sound the buzzer.


-
- 1) Press ⓐ in the daily alarm mode to set hour. One hour advances with every push of ⓐ. Keep pressed to change at high speed.
 - 2) Press ⓐ to set minute digits. One minute advances with every push of ⓐ. Keep pressed to change at high speed.
 - 3) Press ⓐ to complete.*

*If the ⓐ button is pressed, the watch reverts to the regular timekeeping mode.

ON or OFF setting of daily alarm and time signal




STOPWATCH OPERATION



- Net time measurement:** (Start) → (Stop) → (Reset)
 - Split time measurement:** (Start) → (Split) → (Split release) → (Stop) → (Reset)
 - 1st-2nd place times:** (Start) → (Split) → (Stop) → (Split release) → (Reset)
- Additional labels for split times: (Split) First finisher, (Split release) Second finisher. Record time of second finisher.

SETTING REGULAR TIME AND CALENDAR

-
- 1) Press ⓐ three times to change regular timekeeping mode to time/calendar setting mode.
 - 2) Press ⓐ on a time signal to correct seconds.
 - 3) Press ⓐ to shift flashing digit(s). Digit(s) to be changed will flash.



- 4) Each press of ⓐ increments digit. Keep pressed to change at high speed.
- Auto-retrieve function**
Display automatically returns to regular timekeeping mode display if no button is pressed for 2 to 3 minutes.
- Independent correction**
Correction of any digit(s) can be skipped by pressing ⓐ.
- 5) Press ⓐ to complete setting.