



# Module No. 834

This Manual applies to both "mile" display and "km" display. Some informations, therefore, may differ from your timepiece.

## READING THE DISPLAY




## SETTING TIME AND DATE



Display automatically returns to the time display if left unused for a few minutes.

## USING FOOTBALL TIMER/COUNTDOWN ALARM



This function combines the Football timer and the Countdown alarm. **FOOTBALL TIMER** is preset to 45 minutes. **COUNTDOWN ALARM** is settable from 1 minute to 60 minutes.

### USING THE TIMER


1) Press (B) in the FOOTBALL TIMER/COUNTDOWN ALARM MODE to switch between timers.



- If the **COUNTDOWN ALARM** is selected, the measuring time should be set by pressing (C).
- Press (D) to start/stop.
- Press (C) to reset to the measuring time while the timer is not running.

A signal confirms start/stop and reset operation. When display reaches 0, a beeper sounds for 10 seconds. Pressing any button stops the beeper. Countdown alarm automatically repeats the countdown.

## USING STOPWATCH



A signal confirms start/stop and split/reset operation. (Working range) Total elapsed time display is limited to 59 minutes 59.99 seconds. For longer times reset and started again.


### a) Net time measurement




### b) Split time measurement



### c) 1st-2nd place times



## USING DAILY ALARM



The alarm beeper will sound for 20 seconds every day at the preset time until cleared when daily alarm is set. Press any button to stop beeper. A signal will sound every hour on the hour if time signal is set.

### Setting daily alarm

- Press (B) in the DAILY ALARM MODE to set new alarm time.
- Each press of (A) shifts flashing position.



- Pressing (D) increase the digit one by one. Hold down for rapid advance.
- Press (B) to complete. Display automatically returns to initial alarm mode display if left unused for a few minutes.

### On or off setting of alarm and time signal

